

ABB MEASUREMENT & ANALYTICS | DATA SHEET

## AX460, AX466 and AX416

Single and dual input analyzers for pH/Redox (ORP)



# Measurement made easy

More processing power, higher performance

## **Cost effective**

 select one or two pH/Redox (ORP) inputs or combine pH/Redox (ORP) and conductivity in one analyzer

## **Reduced installation cost**

easy access terminations; reduced panel space

## High functionality at minimum cost

- three alarms and two fully isolated current outputs
- integral water / chemical sensor cleaner control
- integral PID controller (AX460)

## **Expanded monitoring and control**

- add-on option board provides a total of five alarm relays and four current outputs
- service logbook providing historical data

## On line assurance of reliability

comprehensive sensor and instrument self-checking

## **Energy saving**

high visibility, backlit display with auto switch-off function

## **Reduced yearly maintenance costs**

• 12 to 30 V DC option negates the need for costly safety tests

## Wide range of applicability

- water and waste water treatment
- power, pure water
- semiconductors
- chemicals
- pharmaceuticals
- pulp & paper

#### The AX400 series

AX400 analyzers incorporate the latest technology to provide highly reliable, flexible, feature-packed devices that satisfy a diverse range of process monitoring and control applications. The complete range encompasses solutions for pH/Redox (ORP), conductivity and dissolved oxygen.

AX46x analyzers enable continuous measurements of one or two pH or Redox (ORP) points with simultaneous local display and retransmission. AX46x is used with glass, enamel and antimony pH electrodes and metal Redox sensors, providing measurements with exceptional accuracy and performance.

AX400 series analyzers are available for either wall-/pipe- or panel-mounting and are rated to IP65.

## High functionality as standard

All versions are supplied with two, fully isolated current outputs as standard, that can be assigned to the measured parameter, sample temperature or any appropriate calculated variables.

Three programmable relay set points are available that can also be assigned as required.


Innovative features such as power-saving display and a diagnostic current output option all contribute to a low cost of ownership.

## Plug-and-produce expanded control

An advanced function card provides an additional two current outputs and two further alarm relays that can be assigned to either measured values or sample temperature.

ABB plug-and-produce software automatically reconfigures the analyzer if an option board is added later. No user programming is necessary.

A real-time clock and logbook are also included, making the full-facility versions extremely powerful and versatile.



AX400 outputs

# Significantly reduced maintenance costs

The AX400 analyzers are supplied as standard for 85 to 265 V AC operation. There are no inner switches to set.

They can also be provided for 24 V AC or 12 to 30 V DC supply and recognize automatically which of the two supplies is being used. 24 V DC operation reduces maintenance costs significantly by negating the need for costly, yearly safety tests to ensure compliance with safety procedures.

### Energy saving display

The backlit display has been designed to operate in all types of environments and shows both the measured parameter(s) and, on a separate 16-character display line, diagnostic and computed information.

On dual-input analyzers both measured parameters are displayed simultaneously.

For conservation of energy, the backlight can be set to switch off automatically after 60 s of inactivity.



Backlight can be set to switch off when inactive

### Easy access installation terminals

Easy access to the terminations ensures rapid and costeffective installation. The wall-/pipe-mount version has been designed to ensure that cable connection is simple and convenient. Ingress protection of the electronics section is retained even when the terminal compartment is opened.




AX400 termination chamber makes access easy

## Dual input measurement for critical duties


The AX400 enables two continuous measurements with simultaneous local display and retransmission. This capability provides an on-line validation of the process measurement.

Making two simultaneous measurements and configuring one of the set points as a difference alarm provides continuous on-line checking and early warning of an invalid measurement.



Dual-input comparator for critical measurements


Detecting breakthrough of ammonia in a chiller unit is made possible with dual measurement. Comparison before and after the chiller ensures extremely rapid leakage detection, preventing damage to the system.



Ammonia leakage detection in a chiller unit

### Waste treatment pH and Redox (ORP)


pH and Redox (ORP) are essential control parameters when removing toxic chromium ions from waste water in metalfinishing applications. Dual pH and Redox analyzers and integral control simplifies installation and reduces investment costs.



Waste treatment pH and Redox (ORP)

### Just-in-time maintenance

One of the most vulnerable times for a pH electrode is during reintroduction into the line. If used with a solution earth rod, AX46x analyzers with advanced diagnostic facilities can detect sensor breakages as they occur. In addition, they can detect sensors out-of-process and several reference faults for fault diagnosis and reduced downtime.



Just-in-time maintenance.


-

## Reduced maintenance through in-line cleaning

Many installed pH sensors benefit from regular cleaning. When carried out manually, this can be laborious and costly – so is often ignored. Advanced AX400 pH analyzers make it possible to automate sensor cleaning by using a programmable wash-timer contact to activate a cleaning agent valve or pump.

Pulsed water-wash and jet-wash chemical clean actions are standard, user-selectable functions. The frequency and duration of the wash can be tuned to meet the requirements of the application.

For chemical cleaning a 60 liter (13 gallon) sensor cleaning station can be supplied (model no. AA0010), complete with delivery pump and low level alarm. Chemical cleaning has proved particularly successful on potable drinking water plants where manganese and iron in the sample can create unacceptably high levels of maintenance. Effective cleaning reduces cost of ownership.



Efficient auto-cleaning control for one or two sensor systems

#### Combined conductivity and pH

The AX416 version measures conductivity and pH with the same analyzer. The option board provides the capability to retransmit pH, conductivity and both sample temperatures. Five programmable alarms can be assigned to suit the needs of the application, enabling even the most demanding requirements to be met.




Simultaneous conductivity and pH measurement

## AX460 integral P, PI and PID control

The single input AX460 analyzers incorporate three-term PID Control, offering three modes of sophisticated control: analog, pulse length (time proportional) and pulse frequency. These are supplied as standard and can be operated in director reverse-acting mode, dependent upon the application.


#### Auto / Manual and bumpless transfer

An auto / manual feature is incorporated for rapid manual access to the control functions. The controller facilitates bumpless transfer between manual and auto modes, providing the measured variable is within the proportional band and some integral action time has been programmed.



#### Current output proportional control

In this case, the control signal is provided by the 4 to 20 mA output of the AX460 analyzers rather than using the alarm / control contacts. The magnitude of the current output changes in proportion to the deviation from set point. This method is used generally with motorized valves or when controlling the speed of dosing pumps with a 4 to 20 mA proportional input.




Current acting control

#### Time proportioning control (pulse length)

With time proportioning control, the AX460 analyzer's control signal output is in pulses, the duration of which changes in proportion to the system error. The pulses are delivered by varying the length of time that the alarm / control contact is activated.

Time proportioning control is used generally to control dosing by low-cost solenoid valves or metering pumps and is also known as pulse-length proportional or 'Mark Space' control.



Time proportioning control


AX460 – integral P, PI, and PID control

#### **Bi-directional control**

As well as single set point control for both acid and base addition, the AX460 analyzer can be configured with independent controllers.

To avoid control overlap, a minimum of 0.5 pH difference (or deadband) between the set points is essential. The difference between the set points varies depending upon the application.

Control of each set point can be configured independently as either P or PI control in this mode. The setting of proportional band or integral action can also be different for each set point.



**Bi-directional control** 


#### Pulse-frequency proportional control

Impulse pumps dosing chemical reagents are controlled easily by the AX460 analyzer's pulse-frequency proportional control output. In this case, the pulse length of the alarm / control contact is fixed and the frequency of the delivered pulses increases in proportion to the system error, as set by the proportional band. Diaphragm metering pumps must have a remote pulse input capability in order to utilize this function.

Pulse-frequency control in the AX460 analyzer operates by pulsing a relay on for 300ms and off for a period of time determined by the pulse frequency. The pulse frequency (PFr) is adjustable between 1 and 120 pulses per minute. The greater the difference between the measured variable and the set point the greater the pulse frequency.

#### Example

If the pulse frequency is set at 120 pulses per minute and the percentage output is 100 % then the pulse rate is 2 pulses per second. If the percentage output is reduced to 50 %, the pulse rate falls to one pulse per second.



Pulse-frequency proportional control

#### Power failure recovery

In the event of a power failure the user can configure the control mode to be Auto, Manual or Last. This optimizes control conditions on power-up to ensure rapid recovery of process control.

## Specification

## pH/Redox (ORP) – AX460 and AX466

Inputs

- One or two\* pH or mV inputs and solution earth
- One or two\* temperature sensors
- Enables connection to glass or enamel pH and reference sensors and Redox (ORP) sensors

#### Input resistance

- Glass >1 x 10<sup>13</sup>Ω
- Reference 1 x  $10^{13}\Omega$

#### Range

–2 to 16 pH or –1200 to +1200 mV

Minimum span

Any 2 pH span or 100 mV

Resolution

0.01 pH

Accuracy

0.01 pH

#### Temperature compensation modes

- Automatic or manual Nernstian compensation
  - Range –10 to 200 °C (14 to 392 °F)
- Process solution compensation with configurable coefficient
  - Range –10 to 200 °C (14 to 392 °F)
- adjustable –0.05 to 0.02 %/°C (–0.02 to 0.009 %/°F)

#### Temperature sensor

Programmable Pt100, Pt1000 or Balco  $3k\Omega$ 

#### **Calibration ranges**

Check value (zero point)

0 to 14 pH

Slope

Between 40 and 105 % (low limit user configurable)

#### **Electrode calibration modes**

Calibration with auto-stability checking

- Automatic 1 or 2 point calibration selectable from:
  - ABB
  - DIN
  - Merck
  - NIST
  - US Tech
- 2 x User-defined buffer tables for manual entry,
   2-point calibration or one-point process calibration

#### Conductivity – AX416 only Range Programmable 0 to 0.5 to 0 to 10,000 $\mu$ S cm<sup>-1</sup> (with various cell constants) Minimum span 10 x cell constant Maximum span 10,000 x cell constant Units of measure $\mu$ S cm<sup>-1</sup>, $\mu$ S m<sup>-1</sup>, mS cm<sup>-1</sup>, mS m<sup>-1</sup>, M $\Omega$ -cm and TDS Accuracy Better than $\pm 0.01$ % of span (0 to 100 $\mu$ S cm<sup>-1</sup>) Better than $\pm 1$ % of reading (10,000 $\mu$ S cm<sup>-1</sup>) Operating temperature range -10 to 200 °C (14 to 392 °F) Temperature compensation -10 to 200 °C (14 to 392 °F) Temperature coefficient Programmable 0 to 5 %/°C and fixed temperature compensation curves (programmable) for acids, neutral salts and ammonia **Temperature sensor** Programmable Pt100 or Pt1000 **Reference temperature**

25 °C (77 °F)

#### Display

Type Dual 5-digit, 7-segment backlit LCD Information 16-character, single line dot-matrix Energy-saving function Backlit LCD configurable as ON or Auto-Off after 60 s Logbook\*\* Electronic record of major process events and calibration data Real-time clock\*\*

Records time for logbook and auto-manual functions

#### Relay outputs - on/off

Number of relays Three supplied as standard or five

with option board fitted

#### Number of set points

Three supplied as standard or five with option board fitted

#### Set point adjustment

Configurable as normal or failsafe high / low or diagnostic alert

#### Hysteresis of reading

Programmable 0 to 5 % in 0.1 % increments **Delay** 

Programmable 0 to 60 s in 1 s intervals

#### **Relay contacts**

Single-pole changeover

Rating 5 A, 115 / 230 V AC, 5 A DC

#### Insulation

2 kV RMS contacts to earth / ground

#### Analog outputs

Number of current outputs (fully isolated)

Two supplied as standard or four with option board fitted **Output ranges** 

- 0 to 10, 0 to 20 or 4 to 20 mA
- Analog output programmable to any value between 0 and 22 mA to indicate system failure

#### Accuracy

 $\pm 0.25$  % FSD,  $\pm 0.5$  % of reading (whichever is the greater) Resolution

0.1 % at 10 mA , 0.05 % at 20 mA

#### Maximum load resistance

 $750\Omega$  at 20 mA

#### Configuration

Can be assigned to either measured variable or either sample temperature

#### **Digital communications**

#### Communications

Profibus DP (with option board fitted)

#### Control function – AX460 only Controller type P, PI, PID (configurable) **Control outputs** Output Can be assigned a maximum of two relays, two analog outputs, or one of each Analog Current output control (0 to 100 %) Time proportioning cycle time 1.0 to 300.0 s, programmable in increments of 0.1 s Pulse frequency 1 to 120 pulses per minute, programmable in increments of 1 pulse per minute **Controller** action Reverse, direct or bi-directional (programmable) Proportional band 0.1 to 999.9 %, programmable in increments of 0.1 % Integral action time (Integral reset)

1 to 7200 s, programmable in increments of 1 s (0 = Off) Derivative

0.1 to 999.9 s in increments of 0.1 s -

only available for single set point control

#### Auto / Manual

User-programmable

#### Access to functions

#### Direct keypad access

- Measurement, maintenance, configuration, diagnostics and service functions
- Performed without external equipment or internal jumpers

#### Sensor cleaning function

Configurable cleaning action relay contact

- Continuous
- Pulse in 1 s on and off times

#### Frequency

5 minutes to 24 hours, programmable in 15 minute increments up to 1 hour then in 1 hour increments for 1 to 24 hours

#### Duration

15 s to 10 minutes, programmable in 15 s increments up to 1 minute then in 1 minute increments up to 10 minutes

#### **Recovery period**

30 s to 5 minutes, programmable in 30 s increments

## ....Specification

#### Mechanical data

#### Wall- / Pipe-mount versions

- IP65 (not evaluated under UL certification)
- Dimensions 192 mm high x 230 mm wide x 94 mm deep (7.56 in. high x 9.06 in. wide x 3.7 in. deep)
- Weight 1 kg (2.2 lb.)

#### Panel-mount versions

- IP65 (front only)
- Dimensions 96 mm x 96 mm x 162 mm deep (3.78 in. x 3.78 in. x 6.38 in. deep)
- Weight 0.6 kg (1.32 lb.)

#### Cable entry types

Standard5 or 7 x M20 cable glandsNorth American7 x knockouts suitable<br/>for ½ in. Hubble gland

#### **Power supply**

#### Voltage requirements

- 100 to 240 V AC, 50 / 60 Hz (90 V min. to 264 V max. AC)
- 12 to 30 V DC
- Power consumption

#### 10 W

- Insulation
  - Mains to earth (line to ground) 2 kV RMS

#### **Environmental data**

Operating temperature limits

- –20 to 55 °C (–4 to 131 °F)
- Storage temperature limits
- –25 to 75 °C (–13 to 167 °F)
- Operating humidity limits Up to 95 %RH non condensing

#### EMC

Emissions and immunity

Meets requirements of:

- EN61326 (for an industrial environment)
- EN50081-2
- EN50082-2

#### Approvals, certification and safety

Safety approval

- UL
- CE mark
  - Covers EMC & LV Directives
  - (including latest version EN 61010)

## General safety EN61010-1

- Overvoltage Class II on inputs and outputs
- Pollution category 2


#### Languages


#### Languages configurable:


- English
- French
- German
- Italian
- Spanish

## **Overall dimensions**

Dimensions in mm (in.)










Pipe-mount detail

Wall- / Pipe-mount version










5.4 (0.21)

### **Electrical connections**



Terminal block B						
Sensor B	Sensor A	pH/Redox (ORP) without solution earth‡	pH/Redox (ORP) with solution earth‡	Conductivity		
1	9	Temperature compensator common* Link 1 & 2 / 9 & 10**	Temperature compensator common* Link 1 & 2 / 9 & 10**	Temperature compensator common Link 1 & 2 / 9 & 10**		
2	10	Temperature compensator third lead*	Temperature compensator third lead*	Temperature compensator third lead		
3	11	Temperature compensator*	Temperature compensator*	Temperature compensator		
4	12	Not applicable	Reference electrode	Screen		
5	13	Not used	Not used	Cell (cell electrode)		
6	14	Reference electrode	Solution earth‡	Cell (earth electrode)		
7	15	Screen*	Screen*	Not used		
8	16	Glass / Metal electrode	Glass / Metal electrode	Not used		

\*If fitted.

\*\*When a 2-wire Pt100, Pt1000 or BALCO temperature compensator is fitted. \$Solution earth also referred to as ground rod. Ordering information

Single and dual input analyzers for pH/Redox (ORP) and conductivity models AX460, AX466 and AX416	AX4 X	X	X	X	X	0
First process variable (PV1)						
Conductivity 0 to 10,000 $\mu$ S cm <sup>-1</sup> for 2-electrode sensors	1					
Conductivity 0 to 1,999 mS cm <sup>-1</sup> for 4-electrode sensors	3					
Conductivity USP<645> for 2-electrode sensors	5					
pH/Redox (ORP)	6					
Dissolved oxygen	8					
Second process variable (PV2)*						
No second process variable – select for PID control of PV1		0				
Conductivity 0 to 10,000 $\mu$ S cm <sup>-1</sup> for 2-electrode sensors		1				
Conductivity 0 to 1,999 mS cm <sup>-1</sup> for 4-electrode sensors**		3				
Conductivity USP<645> for 2-electrode sensors		5				
pH/Redox (ORP)		6				
Dissolved oxygen		8				
Enclosure types						
Wall-mount IP65, general						
Wall-mount – cable glands fitted			1			
Pipe-mount			2			
Wall-mount IP65, North American						
Wall-mount			6			
Pipe-mount			7			
Panel-mount, universal			_			
Panel-mount**			5			
Advanced functions and communications						
Basic (2 current outputs + 3 relays)				0		
Advanced (4 current outputs + 5 relays + logbook)				1		
Profibus DP, basic (2 current outputs + 3 relays)**				2		
Profibus DP, advanced (4 current outputs + 5 relays + logbook)**				3		
Power supply						
100 to 240 V AC 50 / 60 Hz					0	
12 to 30 V DC					1	
Reserved						0
Manual						
English						
French						
Italian						
German						
Spanish						

digit for PV1 (for example, AX416 is permissible, AX461 is not permissible). \*\* Profibus DP is not available in panel-mount housing when 0 to 1,999 mS/cm is selected as the second process variable (PV2).



PROFIBUS is a registered trademark of PROFIBUS and PROFINET International (PI).

-









#### **ABB** Limited **Measurement & Analytics**

Oldends Lane, Stonehouse Gloucestershire, GL10 3TA UK Tel: +44 (0)1453 826 661 Fax: +44 (0)1453 829 671

#### ABB Inc.

#### **Measurement & Analytics**

125 E. County Line Road Warminster, PA 18974 USA Tel: +1 215 674 6000 Fax: +1 215 674 7183

#### abb.com/measurement

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB.

© Copyright 2018 ABB. All rights reserved.

DS/AX4PH-EN Rev. M 03.2018